

OPERATING INSTRUCTIONS
FOR MODEL 2660

INSTALLATION

YOUR NEW DELUXE 60 SPECIAL POPCORN MACHINE IS COMPLETELY ASSEMBLED. REMOVE ALL PACKING MATERIAL AND TAPE BEFORE STARTING OPERATION.

CONTROLS

THERE ARE THREE SWITCHES ON THE POPPER.

1. LIGHT AND WARMER SWITCH - TURNS ON HEAT TO BOTTOM CORN PAN AND LIGHT.
2. KETTLE MOTOR SWITCH - TURNS ON MOTOR WHICH DRIVES KETTLE AGITATOR SHAFT.
3. KETTLE HEAT SWITCH - TURNS ON HEAT ELEMENT.

AMOUNT OF POPCORN AND OIL

POPPING CORN IN YOUR NEW DELUXE 60 SPECIAL 6 oz. POPCORN POPPER IS EASY BECAUSE OF THE PRE-MEASURED OIL AND POPCORN/SALT POUCHES.

POPPING INSTRUCTIONS

1. TURN KETTLE HEAT AND KETTLE MOTOR SWITCH ON.
2. LET KETTLE HEAT FOR 4 MINUTES.
3. LOAD ONE PRE-MEASURED POUCH OF OIL AND ONE PRE-MEASURED POUCH OF CORN INTO KETTLE.
4. WHEN CORN HAS POPPED, DUMP KETTLE.
5. IMMEDIATELY RELOAD KETTLE WITH OIL AND CORN.
6. ON THE LAST BATCH YOU ARE GOING TO POP, TURN KETTLE HEAT SWITCH OFF ONCE LIDS START TO LIFT FROM KETTLE. THIS WILL KEEP SMOKE DOWN TO A MINIMUM.

CARE AND CLEANING

FOR CARE AND CLEANING INSTRUCTION, SEE PAGE 1 OF THE MANUAL.

ALWAYS UNPLUG POPPER BEFORE CLEANING

NEVER IMMERSE ANY PORTION OF THE KETTLE IN WATER.

NEVER FLOOD CABINET WITH WATER DURING CLEANING.



513-521-6500

9832 Hamilton Ave. Cincinnati, OH 45231